



# RUST BULLET® METAL BLAST SPRAY & GO PUMP INSTRUCTIONS

- Container Treats up to 400 Square Feet
- Eliminates Hand Fatigue: 1 Pump up Equals 50 Trigger Pulls
  - Provides up to 10 Minutes of Continuous Spray
  - Pre-Filled with 1 Gallon of Rust Bullet Metal Blast

## Assembly and Use

	<p><b>1. OPEN</b> Carefully cut open the top of the box with scissors or knife. Use caution not to go too deep and cut the spray hose.</p>		<p><b>5. PUMP</b> Pump container 15-20 times to pressurize bottle. More pumps are required for less full bottles. Pumping at the higher range provides longer spray duration. After pumping, push pump down and turn handle clockwise to lock into carrying position.</p>
	<p><b>2. ASSEMBLY 1 of 3</b> Unscrew the retaining cap from the end of the spray hose. Set in a safe place as it will be used to attach the wand to the spray hose in the next steps.</p>		<p><b>6. SPRAY</b> Aim wand. Spray by pressing down the trigger on handle of spray hose. Adjust spray pattern by rotating nozzle tip up to one half rotation.</p>
	<p><b>3. ASSEMBLY 2 of 3</b> Take the retaining cap that you removed in part 1 and slide onto the wand as shown in the picture. Ensure threads are facing toward the bottom of your spray wand.</p>		<p><b>7. DEPRESSURIZE</b> When done using sprayer and before storing, push pump handle all the way down and turn handle into locked position. Lift up on pressure valve until you no longer hear air escaping from the bottle.</p>
	<p><b>4. ASSEMBLY 3 of 3</b> Insert wand with retaining cap still attached into open hole at end of spray hose. Slide retaining cap down onto the end of the spray hose and secure tightly, being careful not to over tighten and strip threads.</p>		<p><b>8. REFILL</b> Carefully refill with Rust Bullet Metal Blast as needed by unscrewing the top cap. The sprayer has a maximum capacity of 1 gallon; do not overfill. Once filled, screw the top back on tightly and securely.</p>