



RUST BULLET® METAL BLAST

SPRAY & GO

PUMP INSTRUCTIONS

- Container Treats up to 400 Square Feet
- Eliminates Hand Fatigue: 1 Pump up Equals 50 Trigger Pulls
 - Provides up to 10 Minutes of Continuous Spray
 - Pre-Filled with 1 Gallon of Rust Bullet Metal Blast

Assembly and Use

	<p>1. CUT Carefully cut the two zip ties securing the hose and pump handle with scissors or knife. Use caution not to cut the spray hose.</p>		<p>5. SPRAY Aim wand. Spray by pushing down white trigger with thumb. Adjust spray pattern by rotating nozzle tip up to one half rotation.</p>
	<p>2. CONNECT Unwind hose. Firmly push the connector at the end of the hose onto the spout on the pump, until it locks into place.</p>		<p>6. STORE When finished spraying, push the yellow button and push wand back until yellow button snaps back into original storage position. Place wand back onto the bottle with nozzle facing down.</p>
	<p>3. EXTEND WAND Lift wand off bottle. Push yellow button while pulling out on the wand nozzle tip. Fully extend wand until yellow button snaps into SPRAY position. NOTE: White trigger will not function until wand is fully extended and yellow button is visible in the spray position.</p>		<p>7. DEPRESSURIZE Push pump handle all the way down and turn handle and cap counter-clockwise to relieve pressure, then retighten.</p>
	<p>4. PUMP Pump container 15-20 times to pressurize bottle. More pumps are required for less full bottles. Pumping at the higher range provides longer spray duration. After pumping, push pump down and turn handle clockwise to lock into carrying position. NOTE: This bottle is designed to expand under pressure and cannot be over-pressurized.</p>		<p>8. REFILL Carefully refill with Rust Bullet Metal Blast as needed by unscrewing the top cap. The sprayer has a maximum capacity of 1.33 gallons; do not overfill. Once filled, screw the top back on tightly and securely.</p>